



## INSTALLATION, OPERATION AND MAINTENANCE MANUAL



### Air Curtains WINDBOX BB

*Please, read these instructions carefully before attempting installation*

#### SECURITY ADVISE SYMBOLS



*Attention, Danger, Safety Advice!*



*Danger from electric current or high voltage!*



*Injuries risk!*



*Danger! Do not stay underneath: Heavy load.*




*Important information.*

**AIRDOM05521-R14 (13/05/24)**


**INDEX**

CONNECTION DIAGRAM – ELECTRICAL MODELS .....	3
CONNECTION DIAGRAM – WATER AND UNHEATED MODELS .....	4
INSTALLATION .....	5
Power Supply .....	6
PCBoard and Control .....	6
Fixing .....	6
Water coils .....	6
Electrical elements .....	6
STORAGE AND TRANSPORT .....	7
WORKING INSTRUCTIONS .....	7
Characteristics of regulation boards .....	7
WIRING DIAGRAMS .....	7
DATASHEET .....	13
MAINTENANCE INSTRUCTIONS .....	17
External cleaning.....	17
Internal cleaning.....	17
REPAIRS AND REPLACEMENTS .....	18
Fan replacement .....	19
Fuse and PCB replacement (only electrical heated).....	19
Heater replacement.....	20
FAILURES AND SOLUTIONS .....	21
DECLARATION OF CONFORMITY .....	22
Air curtain identification .....	23
GUARANTEE .....	23

# CONNECTION DIAGRAM – ELECTRICAL MODELS




**CONNECTION DIAGRAM – WATER AND UNHEATED MODELS**



## INSTALLATION

Valid for models: **Windbox BB**



(m)

H MAX	
<b>M</b>	3,5 m
<b>ECM</b>	3,8 m
<b>G</b>	4 m
<b>ECG</b>	4,2 m
<b>BB</b>	5,7 m

(mm)

	A	B	C	D
<b>MG</b>				330
<b>BB</b>	200	100	200	370
<b>LXL</b>	(Min)	(Min)	(Min)	1142

H MAX: Maximum recommended height, Min: Minimum recommended distance

(\*) Standard units. Under request this distance can be reduced up to 1cm when connections are placed inside and when lateral water pipes.

Minimum recommended distance between the inlet grille and any obstacle is of 200 mm.

	<p><b>Installation work, connection, disconnection, electrical wiring, mechanical maintenance and service must be done by qualified people observing these instructions and in accordance with all applicable norms and standards.</b></p> <p><b>If the unit is operated with additional controller, please consider its specific instructions.</b></p>
	<p><b>There is no need to open the service door to connect the air curtain. All connections (power supply, control, water pipes when existing) and fixations are external. They are placed on top or lateral of the units. See how to open service door at repairs section.</b></p>
	<p><b>For safety, the air curtains never have to be stopped by disconnecting them from the main supply, always through the controller and waiting 10 minutes at least to disconnect the main supply. In case of not follow these instructions, the internal parts of the air curtain can be damaged.</b></p>

---

### **Power Supply**

---

To connect the power supply there is a black connection box outside the air curtain (located on top).

For an ambient air or water heated air curtain, just connect the single phase 230Vx1.

In case of an air curtain with electrical heating we will also connect the three phase 400Vx3 of the electrical element.

---

### **PCBoard and Control**

---

To connect the controller to the curtain, there is a connector located on the top of the outside of the air curtain. It is not necessary to open the curtain to connect it, except for internal connections. Use the 10 meter RJ45 cable supplied with the equipment. The communication between the controller and the board is digital and low voltage.



---

### **Fixing**

---

Units are provided of several external suspension points, depending on the weight and length of each model (see exact situation of the points at the air curtains characteristics page).

Generally, air curtains work horizontally but also can be installed vertically using feet supports (*Accessories* section).

The fixing of the air curtain should be managed according to the weights of each unit shown on the technical data page. The installation can be made through threaded rods, cable tensors or other supports. See available supports in the accessories section.

---

### **Water coils**

---

It is recommended:

- Close the hot water circulation (by turning the electrovalve OFF) to avoid fan overheating while the unit is OFF. Electrovalve is optional.
- Install 2 cutoff water valves (supply and return) in order to disassemble the equipment easily.
- Install a bleeding valve at the highest part of the water heating circuit.

The ambient temperature should be always over +4°C, otherwise it will be necessary to provide an anti-frost protection device.

Water coils have a drainage point placed at the end part of the intake manifolds area.

Some special units are provided with condensation tray prepared to work with cold water. In this case, these units can't work at high ventilation speed (depending on model, length and power it will be a speed limitation). Intake air speed should not be higher than 3m/s because water drops can appear on the outlet.

---

### **Electrical elements**

---

The heater element has resistances bars (the number depends on length) that combined give 3 stages of heating. The control is made by contactors.

All electrical elements are protected electrically and electronically against overheating (see "*Operating instructions*" section).

The electrical controllers have the option to install an external thermostat that turns on/off the heating in order to control the temperature.

During the first uses scent can be emitted but it disappears in a few days.

## STORAGE AND TRANSPORT



**Attention! Heavy load.**  
**Do not step underneath hanging load during the transport or assembly.**

Store in a dry place and weather protected in its original packaging. In case the packing is opened, cover the air curtain to protect it from dust. Do not step or put heavy load over the package to avoid damages to the material. Store temperatures are between -20°C and +40°C.

When carrying material, make sure it is not damaged by the forklift (fork penetration in the packaging). Please see the *Packaging* indications.

## WORKING INSTRUCTIONS



**For safety, the air curtains never have to be stopped by disconnecting them from the main supply, always through the controller and wait for 10 minutes at least to disconnect the main supply. In case to not follow these instructions, the internal parts of the air curtain can be damaged.**

### *Characteristics of regulation boards*

Depending on the type of fan, the air speed is regulated by:

- BB: from 0 - 10V DC voltage range.

## WIRING DIAGRAMS


For the models Windbox BB, the following wiring diagrams are enclosed:

- Warm water heated or only air 1000-2000 with Standard Control. Diagram: AIRDOE09031
- Warm water heated or only air 2500-3000 with Standard Control. Diagram: AIRDOE09034
- Electrical air curtain 1000-1500 with Standard Control. Diagram: AIRDOE09035
- Electrical air curtain 2000 with Standard Control. Diagram: AIRDOE09037
- Electrical air curtain 2500-3000 with Standard Control. Diagram: AIRDOE09039


In case you need to connect the equipment to a PLC, the corresponding wiring diagrams will be supplied.

Air curtain Cortina	Power supply Alimentación	Number of Fans
1000	0,87kW	3
1500	1,16kW	4
2000	1,74kW	6

Reguladores de 5 velocidades  
5 Speeds remote Control





Marcha/Paro externo (opcional)  
ON/OFF Extern (optional)



Q = Interruptor magnetotérmico  
Si el interruptor es de 30mA, recomendamos poner un interruptor por cada cortina.

Q = Circuit breaker  
If uses a 30mA circuit breaker, we recommend to install one Circuit breaker for each air Curtain.

Alimentación  
Power supply  
230Vx1 / 50Hz



Cortina de aire  
Air Curtain 1


ESQUEMAS ELÉCTRICOS CORTINA DE AIRE VENTILADORES EC  
WIRING DIAGRAMS OF AIR CURTAIN EC FANS

CONTROLADOR 5 VELOCIDADES AGUA O AIRE CORTINA BB1000, 1500, 2000  
CONTROLLER 5 SPEEDS. ONLY AIR & WATER. AIR CURTAIN BB 1000, 1500, 2000


Pág./ Page 1 de/  
Doc. AIRDOE09031  
R0 - 26/02/24

Air curtain Cortina	Power supply Alimentación	Number of Fans
2500	2kW	4+3
3000	2.3kW	4+4

Reguladores de 5 velocidades  
5 Speeds remote Control



Marcha/Paro externo (opcional)  
ON/OFF Extern (optional)




Air curtain Cortina	Heating + fan Calefacción + ventilador	Number of Fans
1000 E21kW	21kW + 0.87kW	2
1500 E27kW	27kW + 1.18kW	3

ESQUEMAS ELÉCTRICOS CORTINA DE AIRE VENTILADORES EC  
WIRING DIAGRAMS OF AIR CURTAIN EC FANS


CONTROLADOR 5 VELOCIDADES AGUA O AIRE CORTINA BB 2500, 3000  
CONTROLLER 5 SPEEDS ONLY AIR & WATER. AIR CURTAIN BB 2500, 3000

Pág./ Page 1 de/  
Doc. AIRDOE09034  
RO - 26/02/24

Reguladores de 5 velocidades  
5 Speeds remote Control




Temostato digital (opcional)  
Digital Thermostat (optional)




Temostato (opcional)  
(contacto 'thive') (si se utiliza retirar el puente 4-5)  
Room Thermostat (optional)  
('Freeze' contact) (if used, take out the jumper 4-5)

ON/OFF Extern (opcional) 30 Seconds Delay  
Marcha/Paro externo (opcional) 30 segundos de retardo

Cable 2 (opcional, máximo 12)  
Air Curtain 2 (opcional, Max 12)



Control JK1/JK2/Aux



Cortina de aire  
Air Curtain 1


Air curtain	Power supply + fan	Number
Cortina	Alimentación + ventilador	3
1000 E21	270W + 0,87kW	3
1500 E27	270W + 1,16kW	4

ESQUEMAS ELÉCTRICOS CORTINA DE AIRE BB VENTILADOR EC

WIRING DIAGRAMS OF AIR CURTAIN BB EC FANS  
BB ELECTRICA 400V-3-1000-1500  
ELECTRICAL BB 400V-3-SINGLE POWER SUPPLY 1000-1500

Air curtain	Power supply 1 + fan	Power supply 2	Number of Fans
Option	Alimentación 1 + ventilador	Alimentación 2	6
2000 ECR4W	12kW + 1.7kW	30kW	

Reguladores de 5 velocidades  
5 Speeds remote Control




Termostato digital (opcional)  
Digital Thermostat (optional)

Termostato (opcional)  
(contacto "libre") (si se utiliza, retirar el puente 4-5)  
Room Thermostat (optional)  
("Free" contact) (if used, take out the jumper 4-5)

ON/OFF Externi (opcional) 30 Seconds Delay  
Manchar/Paro externo (opcional) 30 segundos de retardo

Option 2 (optional, internal 12)  
Air Curtain 2 (optional, Max 12)



ESQUEMAS ELÉCTRICOS CORTINA DE AIRE BB VENTILADOR EC


WIRING DIAGRAMS OF AIR CURTAIN BB EC FANS

BB ELECTRICA 400V~3-2000  
ELECTRICAL BB 400V~3-DOUBLE POWER SUPPLY 2000

Cortina de aire  
Air Curtain 1

Página / Page 1 de / of 1  
Doc. AIRDOE09037  
R0 - 26/02/24

Reguladores de 5 velocidades  
5 Speeds remote Control




Termostato digital (opcional)  
Digital Thermostat (optional)

Termostato (opcional)  
(contacto "Tire" ) (if se utiliza, retirar el puente 4-5)  
Room Thermostat (optional)  
("Free" contact ) (if used, take out the jumper 4-5)

Air curtain Cortina	Power supply 1 + fan Alimentación 1 + ventilador	Power supply 2 Alimentación 2	Number of Fans
2500 ESRW	18W + 24W	30W	4/3
3000 ESRW	24W + 24W	30W	4/4

Q = Interruptor magnético  
Q = Circuit breaker



Cortina de aire  
Air Curtain 1

ESQUEMAS ELÉCTRICOS CORTINA DE AIRE BB VENTILADOR EC

WIRING DIAGRAMS OF AIR CURTAIN BB EC FANS  
BB ELECTRICA 400V-3 2500 Y 3000  
ELECTRICAL BB 400V-3 DOUBLE POWER SUPPLY 2500 & 3000


Página / Page 1 de / of 1  
Doc. ARDDE09039  
RO - 26/02/24

# WINDBOX BB

HIGH PRESSURE STANDARD AIR CURTAINS FOR COMMERCIAL AND INDUSTRIAL DOORS



## Technical Features



Range  
Up to 7 m



Airflow / Length  
3750 - 10720 m<sup>3</sup>/h  
1 m to 3 m



Fans  
Centrifugal  
5-speed



Heating types  
E : electrical 3 stages  
P : water  
A : unheated  
DX : heat pump [\*]



Heating capacity  
E : 6 - 50 kW  
P : 15,2 - 55,0 kW



Control  
Plug&Play manual regulator  
+ IR remote control  
(Optional Clever Control)






Casing  
Galvanised Steel [\*\*]



Grille type  
Micro-perforated  
with prefilter function



Outlet lamellas  
Aluminium, airfoil type  
Adjustable 0-15° each side

RAL 9016 standard  Other colors on request  Stainless steel 

[\*] Consult separate DX catalogs

[\*\*] Customizable dimensions on request

Commercial size air curtain with an equivalent power to an industrial unit. As all the standard range of Airtècnics air curtains, WINDBOX BB has an elegant and timeless design. A highly versatile air curtain provided with a wide variety of technical specifications, mounting options and customization, gathering all the latest innovations and developments.

This model works with the latest generation of double-inlet centrifugal high efficiency EC fans driven by an external rotor motor, with low noise level and very low consumption.

Includes Plug&Play control with 7m RJ45 cable and infrared remote control. Optionally can be regulated with Advanced Clever Control (programmable, automatic, intelligent, compatible with Modbus RTU for BMS).

### UNHEATED

Model	Airflow m <sup>3</sup> /h	Ventilation power 230V~50Hz kW	Ventilation current 230V~50Hz A	Noise level (5 m) dB (A)	Weight kg
BB 1000 A	4020	0,873	3,87	66	38
BB 1500 A	5360	1,164	5,16	67	55
BB 2000 A	8040	1,746	7,74	68	77
BB 2500 A	9380	2,037	9,03	69	93
BB 3000 A	10720	2,328	10,32	70	110



 ELECTRIC HEATED

Model	Airflow m <sup>3</sup> /h	Electrical heating capacity 400Vx3~50Hz (*) kW	Ventilation power 230V~50Hz kW	Ventilation current 230V~50Hz A	Noise level (5 m) dB(A)	Weight kg
BB 1000 E	4020	6/15/21	0,873	3,87	66	49
BB 1500 E	5360	8/19/27	1,164	5,16	67	71
BB 2000 E	8040	12/30/42 (**)	1,746	7,74	68	98
BB 2500 E	9380	16/30/46 (**)	2,037	9,03	69	119
BB 3000 E	10720	20/30/50 (**)	2,328	10,32	70	141

(\*) Under request other electrical heating power can be limited.

(\*\*) 2 separated power supplies.

 WATER HEATED

Model	Airflow m <sup>3</sup> /h	P86 (80/60°C)		P64 (60/40°C)		P54 (50/40°C)		Ventilation power 230V~50Hz kW	Ventilation current 230V~50Hz A	Noise level (5 m) dB(A)	Weight kg
		Water heating capacity kW	Water pressure drop Pa	Water heating capacity kW	Water pressure drop Pa	Water heating capacity kW	Water pressure drop Pa				
BB 1000 P	3750	18,21	15190	15,16	16190	16,48	12180	0,873	3,87	65	47
BB 1500 P	5000	23,52	1200	21,87	10990	24,15	15260	1,164	5,16	66	67
BB 2000 P	7500	36,57	3470	31,13	7350	35,04	12680	1,746	7,74	67	93
BB 2500 P	8750	45,78	6370	38,96	13420	42,12	11880	2,037	9,03	68	115
BB 3000 P	10000	55,04	10570	45,49	11230	49,27	10920	2,328	10,32	69	135

Water heated:

P86, P64 2x1", P54 1000-2000 2x1" and 2500-3000 2x1 ¼".

Connection pipes P86, P64 and P54 are male.

P86 2 rows coil, P64 3 rows coil, P54 4 rows coil.




Selection program




## Dimensions


Horizontal installation




Vertical installation



Inside ceiling surface mounting



False ceiling invisible mounting




CAD drawings, BIM files, installation manuals and other documentation






## Installation Configurations



## Optional accessories

### Supports and installation



### Control



### Filters






### Sensors and valves



### Condensation



## MAINTENANCE INSTRUCTIONS

	<b><i>For safety, before any cleaning, disconnect power supply using the controller.</i></b>
	<b><i>It is forbidden to open the service door (risk of electrical discharge and being trapped in fans). Service and maintenance should be done only by introduced and qualified workers.</i></b>
	<b><i>Do not use water or steam for cleaning the internal parts and components of the air curtain.</i></b>

### ***External cleaning***

Air curtains don't need any kind of maintenance except from the cleaning of the casing and the inlet grille. It is recommended to weekly clean the inlet grille. It's important to make sure that the air curtain is OFF, otherwise the dust mixed with a wet cloth would create a kind of paste that will damage the fan rotor when it sucks the air.

Annual cleaning of the discharge area (outlet).

The casing of the air curtain should be cleaned with a wet cloth and non-aggressive detergent. Do not use caustic soap or acids.

The inlet grille prevents the settling of dust and strange objects in the internal elements. It is recommended to check periodically that the inlet grille is free of any object that could interfere the air entrance (plastic bags, papers, etc.).



**In case of a micro drilled inlet grille** (it has filter functions to prevent the entrance of dust to the internal elements) use a vacuum cleaner with a soft brush in order to avoid any damages in the micro drilled grille. We recommend cleaning the grille every week (depending on the amount of the incoming air dust).

### ***Internal cleaning***

In models with micro drilled grille is recommended to clean the inside of the unit with a vacuum at least once every two years (\*), best before the winter season, with qualified staff.

(\*). These periods are indicative, depending on the ambient conditions of every installation.

In places with a high number of particles in suspension is desirable to increase the frequency of the internal cleaning (including the city centers, near construction sites, etc.).

## REPAIRS AND REPLACEMENTS



**Installation and electrical connections must be done by qualified workers and following these instructions.**



**Before any repairs are undertaken, please:**

- **Inform people that there is work in progress.**
- **Disconnect the power supply and protect the thermal magnet (so nobody can restart it accidentally).**
- **Make sure there is no tension in the air curtain.**
- **Make sure the fans are stopped.**
- **Use only original spare parts.**




To **open the service door**, follow these steps:

1.- Insert a flat screwdriver between the casing and the grille and push the grill out. The grille is closed by pressure through pivots. It has a safety cable to avoid accidental falls.



2.- **OPTIONAL:** Remove the security screw of the service door.



3.- Insert a screwdriver and press down next to the pivots to open the service door. In case of an air curtain with **plenum or inlet/outlet kits** the lever must be done from the side of the door where there is an oblong hole, to make it easier the entrance of a flat screwdriver.



## Fan replacement

Before replacing the fan, inform people that there is work in progress, stop the air curtain through the controller and disconnect main supply. Make sure that the unit is without tension and the fans are stationary. Unplug the fan from the cable tree. Remove the fan by loosening the fixing screws and assemble the new fan following the process in reverse order.



## Fuse and PCB replacement (only electrical heated)


Before the replacement, inform people that there is work in progress.

**Disconnect main supply**, make sure that the unit is without tension and that the fans are stationary.

**Fuse replacement:** Open the service door and remove the fuse of the fuse holder by hand or pulling with the help of a screwdriver pressing to the plate and turning in under clockwise, then replace it.



**PCB replacement:** Open the service door (service panel) and simply unscrew the power plate from the inside of the air curtain to remove it and make the necessary repairs.



## Heater replacement

Before the replacement, inform people that there is work in progress, disconnect main supply, and make sure that the unit is without tension and that the fans are stopped. Before proceeding to unfasten the heater fixing screws, we must:

**Water Coils:** Close the shut-off water valves of the building water circuit to the air curtain (supply and return). Open the service door and empty the water from the coil simply removing the draining screw placed in the bottom of the entrance manifold as shown in the photograph.



**Electrical Heaters:** Disconnect the power supply from the electrical element.



Remove the screw-earth of the connection box and disassemble from the equipment.



Unplug the cables to 1, 2, 3 in the connection box.



Unplug the two connectors of plate pressing the fluke.

When we have the coil or heater ready, we proceed to remove the fixation screws to disassemble the coil or heater.

**Fixation points of coils and heaters:** Angle closes door and interior angles.



Finally, with your hands protected, remove the electrical heater carefully in the direction showed in the photo.



To assemble the new heater following the same process in reverse order.

## FAILURES AND SOLUTIONS

**More than 95%** of the complaints are submitted during the start of operation of the equipment and are due to installations errors.

More than 90% of the failures are solved only by **checking the connections**. Following the three following points, we can make sure that the installation is correct:

**A) RJ45 cable manipulated:** The cable that connects the controller to the air curtains is 8 lines crossed RJ45 cable. **If manipulated (cut or removed the connector) and incorrectly joined (reverse way) the air curtain will not work well.** Moreover, it can damage the electronics. To solve the problem just turn the connector of the cable (see connection diagram in the first page).

**B) Wrong connection of the RJ45 cable.** Verify whether the connector position is the correct, between the “control” and “auxiliary”, according to the installation diagram (particularly if there are several air curtains with a single controller).

**C) Wrong current supply/input.** The air curtain input depends on the type of current available and also on the heating type of the unit. Connect the unit according to the connection diagrams of the first page.

More common failures and solutions		
Effect	Problems	Solutions
<b>All lights of the controller are OFF</b>	Is the RJ45 cable the original (not manipulated), with no enlargements either shortenings?	Change the cable or connect it again correctly.
	Does the current reach the connection box?	Connect correctly the terminals of the junction box: Between L and N there must be 230V and if the air curtain goes with three-phase electrical element, there must be 400V among terminals L1, L2 and L3.
	Is the controller connected to the air curtain, to the connector “Control” of the PCBoard?	Connect the cable from the controller to the “Control”, never to the “Aux”.
	Is the fuse of the PCBoard in good conditions?	Check the fuse and replace it in case it is necessary (type T, slow action).
<b>Some lights of the controller are Flashing.</b>	The green LED of the maximum speed flashes when we stop the air curtain after having been operating with heating.	It is not a failure, but a safety mechanism. The air curtain turns on by itself to the maximum speed to get cold and protect its components. When it decreases from the safety temperature, it will stop.
	Some speed or heating lights are flashing when the air curtain is working.	It is a protection mechanism of the air curtain so that the internal parts of the air curtain do not suffer damages. Situations on which the problem continuously recurs and the way to solve it: 1. Inlet grille blocked (objects, dirtiness...) the ambient temperature inside the equipment can increase a lot if the air cannot circulate. Clean the grille. 2. Small room: we recommend installing a thermostat to control the heating power so the protection device does not activate. 3. In case that the ambient temperature is already high, we recommend to lower the power heating or install a thermostat. 4. Inlet air already warm, that comes from another heating equipment beyond the air curtain. Move the air curtain away, place a thermostat in the inlet part of the curtain or lower the heating power. 5. Any motor does not work: call the technical service.
<b>The heating does not work</b>	Does the three-phase current reach the connections box?	Check installation.
<b>The speed and/or the heat changes continuously with no apparent reason but the lights of the controller are not flashing.</b>	Probably the RJ45 cable is near interference sources, transmitters, cable plates, particularly those that supply current to Motors, etc.	Pass the cable the furthest possible away from interference sources, particularly when long distances or use a screened table.


**Declaration CE of conformity / Declaración CE de conformidad**

Manufacturer **Motors i Ventiladors S.L. (AIRTÈCNICS)**  
 Fabricante **Conca de Barberà 6, Pol. Ind. Pla de la Bruguera**  
**08211 Castellar del Vallès (Barcelona) Spain**

We declare, under our sole responsibility, that the product  
*Declaramos, bajo nuestra única responsabilidad, que el producto*

**Air Curtains**  
**Cortinas de aire**

with models / *con los modelos*

**Minibel, Optima, Recessed Optima, Optima Wireless, Recessed Optima Wireless, Optima K, Optima Switch, Recessed Optima Switch, Top, Recessed Compact, Aris, Windbox, Recessed Windbox, Smart, Dam, Recessed Dam, Deco, Kool, Rund, Invisair, Rotowind, Variwind, Zen, Max, Maxwell, Compact Fly, Fly K, Fly KL-KXL, Fly KBB, Windbox BB, Recessed Windbox BB, Zen BB, Invisair BB, Kool BB, Rotowind BB, Zen L-XL, Windbox L-XL, Duojet, Triojet System**

is/are developed, designed and manufactured in accordance with the following directive(s)  
*ha(n) sido desarrollado(s), diseñado(s) y fabricado(s) de acuerdo con la(s) siguiente(s) directiva(s)*

**Low Voltage Directive 2014/35/EU**  
**Directiva Baja Tensión 2014/35/UE**

**Electromagnetic Compatibility Directive 2014/30/EU**  
**Directiva Compatibilidad Electromagnética 2014/30/UE**

**Restriction Certain Hazardous Substances Directive 2011/65/EU (RoHS)**  
**Directiva Restricción Substancias Peligrosas 2011/65/UE**

**Eco-design Energy-related Products Directive 2009/125/EC**  
**Directiva Diseño Ecológico Productos Con Energía 2009/125/CE**

applying the following harmonized standards in particular  
*aplicando las siguientes normas armonizadas en particular*

**LVD: EN 60335-1:2012 + AC:2014 + A11:2014 + A13:2017 + A1:2019 + A:14:2019 + A2:2019**  
**EN 60335-2-30:2009 + A11:2012 + A1:2020 + A12:2020**

**EMC: EN 61000-3-11:2000**  
**EN 61000-3-12:2011**  
**EN 55014-1:2017 + A11:2020**  
**EN 55014-2:2015**  
**EN 62233:2008 + AC:2008**

**RoHS: EN 50581:2012**

Date / Fecha  
 Name / Nombre  
 Position / Cargo

**04/03/2024**  
**Jordi Hierro**  
**Technical Manager / Director Técnico**

**MOTORS I VENTILADORS, S.L.**  
 ESB58967183 - C/ Conca de Barberà, 6  
 08211 Castellar del Vallès  
 Tel. 937159988 - Fax 937159989

<b>Model</b> <i>Modelo</i>	WINDBOX M 2000 E				
<b>Airflow</b> <i>Caudal</i>	3600	m3/h			
<b>Blowers</b> <i>Ventiladores</i>	1,88	A	0,424	kW	230 V/50Hz
<b>Heating capacity</b> <i>Calefacción</i>	80/60 °C		60/40 °C		
<b>Water Coil</b> <i>Agua</i>		kW		kW	
<b>Electric Coil</b> <i>Batería Eléctrica</i>	6/12/18	kW	400V~3 50Hz		
<b>Serial Number</b> <i>Número de Serie</i>	2015-07-06 / 61.990				

### **Air curtain identification**

Each air curtain is identified by a unique serial number printed in a label located inside the door service. There is also indicated the model and their technical characteristics (flow, fans technical characteristics and power heating).

It is indispensable to have this number to facilitate possible replacements or technical information of the air curtain in question.

If you detect some error in this manual, we'll be pleased to receive your *feedback*, it helps us to improve even more.

Airtècnics reserves the right to modify some of the specifications in this manual.

### **GUARANTEE**

Your air curtain is guaranteed for a period of one year from the date of purchase. We will adjust, repair or replace at our discretion from our warehouse any defect, system failure or part found to be defective. The assembly cost out of our warehouse is at buyer expense. The products that, in our eyes, have been inadequately used, incorrectly manipulated, improperly installed, connected to different nominal tensions, modified, repaired by non-authorized workers or that have suffered damages during transport are totally excluded from the guarantee.

*To validate the guarantee it should be correctly filled and enclosed with the invoice that vouches for the buying date. If it is manipulated, it will lose all validity.*

*It is the buyer's responsibility to take the necessary safety measures because in case of a failure or mistake in one of our products, no damages to third parties, sets or installations will occur.*

#### **Guarantee draft**

**Air curtains data:**

Model: ..... Series number: .....  
 Invoice date: ..... Invoice number: .....

**Buyer data:**

Name: .....  
 Address: .....  
 Country: ..... Phone: ..... Fax: .....

**Seller data:**

Name: .....  
 Address: .....  
 Country: ..... Phone: ..... Fax: .....

**Buyer signature and stamp**

**Seller signature and stamp**