




Control Optional inlets	
Control	Closed=
D1 Off	= Curtain Off
D2	= n/a
D3	= n/a
D4 Door	= Closed door

Jumper Aux	
On	Temp1 is Room
Off (no jumper)	Temp1 is EXT

A la Cortina 2 (opcional, máximo 12)
Air Curtain 2 (optional, Max 12)

230Vx1 / 50Hz

