

CONSUMABLE CARTRIDGE INSTALLATION


- 1**  Remove the cartridge cap
- 2**  Check that the wick is inserted OK
- 3**  Screw the cartridge in the reactor chamber

RECESSED UNIT K7


Unscrew the 6 screws and remove the panel to access the interior

ADVANCED REGULATION (CLEVER)

POWER SUPPLY (EXTERNAL CONNECTION BOX)




CLEVER CONTROL INTERIOR CONNECTION (CABLE RJ11 FROM CLEVER PCB TO TFT)



BASIC REGULATION

POWER SUPPLY



RJ45 CABLE (Special Connection)

